

WARNING

TO AVOID FIRE AND EXPLOSION

THIS SYSTEM IS DESIGNED FOR USE WITH LPG ONLY. DO NOT CONNECT CNG TO THIS SYSTEM

1. Close container valves when boat is unattended and in case of leak or fire.
2. Close all appliance valves before opening container valves.
3. Always apply the source of ignition to burner before opening burner valve.
4. Test system for leakage whenever system is used, when system is serviced, or when container is changed as follows:
 - (a) With appliance valves closed and all other valves open, note pressure on the gauge.
 - (b) Close container valve.
 - (c) Ensure pressure remains constant for at least 5 minutes.
 - (d) If pressure drops, locate the leakage by application of soapy water solution at all connections.
 - (e) Repeat test for each container in multi-container systems.
 - (f) Never use flame to check for leaks. Never use soap containing ammonia.

If a leak detection device is installed, these instructions shall be permitted to be modified as appropriate.

5. Mark container locker "For storage of LPG containers only".
6. Keep valves closed and plugged on empty or unconnected containers.



**ace recreational
marine insurance**

This warning label, required by the National Fire Protection Association and the American Boat & Yacht Council, should be installed in plainly visible locations on the outside of each container enclosure and adjacent to each consuming appliance. Please clean the surface of any dirt or oil before affixing the labels. 616679 04/08

WARNING

TO AVOID FIRE AND EXPLOSION

THIS SYSTEM IS DESIGNED FOR USE WITH CNG ONLY. DO NOT CONNECT LPG TO THIS SYSTEM

1. Close container valves when boat is unattended and in case of leak or fire.
2. Close all appliance valves before opening container valves.
3. Always apply the source of ignition to burner before opening burner valve.
4. Test system for leakage whenever system is used, when system is serviced, or when container is changed as follows:
 - (a) With appliance valves closed and all other valves open, note pressure on the gauge.
 - (b) Close container valve.
 - (c) Ensure pressure remains constant for at least 5 minutes.
 - (d) If pressure drops, locate the leakage by application of soapy water solution at all connections.
 - (e) Repeat test for each container in multi-container systems.
 - (f) Never use flame to check for leaks. Never use soap containing ammonia.

If a leak detection device is installed, these instructions shall be permitted to be modified as appropriate.

5. Mark container locker "For storage of CNG containers only".
6. Keep valves closed and plugged on empty or unconnected containers.



**ace recreational
marine insurance**

This warning label, required by the National Fire Protection Association and the American Boat & Yacht Council, should be installed in plainly visible locations on the outside of each container enclosure and adjacent to each consuming appliance. Please clean the surface of any dirt or oil before affixing the labels. 616678 04/08